

Updating the System Firmware

To update the system firmware you need to have the following files. In addition, you need to use a computer and a USB cable.

- VerupEnglish.exe : CC100-20 update software file
- GITKUSBP.dll : CC100-20 software dll file
- main.mot : CC100-20 firmware file

How to update the system firmware


- (1) Copy the three upgrade software files to the same directory in the PC.
- (2) Connect the computer and the CC100-20 via the USB interface.
- (3) Connect the power cable to turn on the power.
- (4) Turn on the standby switch of the CC100-20.
- (5) Execute VerupEnglish.exe.
- (6) The following menu is displayed. Confirm the note shown in the menu.



- (7) Click the Next button to display the following menu.




- (8) Click the Next button to display the following menu.



- (9) Click the Version Upgrade button to start upgrading when you are ready to upgrade.

(10) The following menu will appear during the firmware upgrade procedure.



(11) The following menu will appear when the upgrade is complete.



(12) The Standby LED blinks when the upgrade is complete.

(13) Click the OK button to close the VerupEnglish.exe program.

(14) Turn off the power. (disconnect the power cable from the CC100-20.)

-
- Note:
- Do not use the computer for any other purpose while you are upgrading the firmware.
 - If you fail to upgrade the firmware, perform the following procedure.
 - (1) Connect the power cable to the CC100-20 while pressing the standby switch for more than 5 seconds.
 - (2) Confirm that the standby LED is blinking.
 - (3) Turn off the power.
 - (4) Perform the upgrade procedure again.
-